

"09" - Fault with motor phase winding

Error code	Cause	Result
09	Fault with motor phase winding.	The display shows the error code 09 and the motor cannot work.

Component Description

The three phases of motor construction are applied in our motor, so each phase is supposed to work properly.

Component Location

The phase windings are installed in the motor.

Conditions for Running the Diagnostics

After the system is turned on, the diagnosis runs continuously.

Error Phenomenon

The display shows the error code 09.

Conditions for Clearing the Error Code

After the diagnosis runs and passes, the system works normally.

Troubleshooting

Step 1 Replace the motor.

Step 2 Clear the error code

Conditions: Connect all components, Turn on the system.

Specification	Solution
Error code 09 is inactive.	Repair complete.
Error code 09 is active.	Return to the step 1 or contact BAFANG if all steps have been completed and checked again.